

# Montageanleitung

## SPM1.450 Bürostuhl



(1) Rollen	(2) Fußkreuz	(3) Gasdruckfeder	(4) Mechanik																														
X5																																	
(5) Armlehnen	(6) Sitzfläche	(7) Rückenlehne																															
X2			8-(1) 8-(2) 8-(3)																														
<p>(9)</p> <table border="0"> <tr><td>1.</td><td></td><td>X2 (M6*25mm)</td></tr> <tr><td>2.</td><td></td><td>X2 (M6*30mm)</td></tr> <tr><td>3.</td><td></td><td>X6 (M6*35mm)</td></tr> <tr><td>4.</td><td></td><td>X2 (M8*15mm)</td></tr> <tr><td>5.</td><td></td><td>X3 (M8*20mm)</td></tr> <tr><td>6.</td><td></td><td>X1 (M6*20mm)</td></tr> <tr><td>7.</td><td></td><td>X4 (6*16mm)</td></tr> <tr><td>8.</td><td></td><td>X2 (8mm)</td></tr> <tr><td>9.</td><td></td><td>X1 (5*25*65mm)</td></tr> <tr><td>10.</td><td></td><td>X1 (4*15*45mm)</td></tr> </table>				1.		X2 (M6*25mm)	2.		X2 (M6*30mm)	3.		X6 (M6*35mm)	4.		X2 (M8*15mm)	5.		X3 (M8*20mm)	6.		X1 (M6*20mm)	7.		X4 (6*16mm)	8.		X2 (8mm)	9.		X1 (5*25*65mm)	10.		X1 (4*15*45mm)
1.		X2 (M6*25mm)																															
2.		X2 (M6*30mm)																															
3.		X6 (M6*35mm)																															
4.		X2 (M8*15mm)																															
5.		X3 (M8*20mm)																															
6.		X1 (M6*20mm)																															
7.		X4 (6*16mm)																															
8.		X2 (8mm)																															
9.		X1 (5*25*65mm)																															
10.		X1 (4*15*45mm)																															

