


Vehicle Logistics

Always know the exact position of all vehicles in your fleet and use this in combination with automatic area monitoring for optimized fleet management.



Vehicle locations at a glance

With Vehicle Logistics, you can output the locations of your fleet vehicles in business mode as a list or map view in the connect business portal: for the entire fleet, for specific groups or for individual vehicles.

Establishing geofences

By creating geofences, you can track exactly when vehicles enter or leave certain areas. If the border of a geofence is crossed, you will be notified directly by the portal and can take appropriate action.

Know more and act more efficiently



Know the current **location** of all fleet vehicles



Reduction of **theft** and **misuse**



Optimization of **order management**



Display of **insurance policies**



Modifiable **notification concept**

Data and functions

Available data

Vehicle position

GPS data

Functions

Display of last known vehicle position

Creation of geofences for area monitoring

Different shapes for geofences: Circle, rectangle or polygon

Configurable notification concept for crossing geofence borders

Display of routes in map view