




Alt-Batterien sowie Altkumulatoren, welche nicht von Altgeräten unschlossen sind bzw. einfach entfernt werden können, sowie Lampen, welche zerstörungsfrei entfernt werden können, müssen getrennt entsorgt werden.

Verbreiter von Elektro- und Elektronikgeräten (Verkaufsfläche min. 400m²) sowie Verleiher von Lebensmitteln (Verkaufsfläche min. 800m²), die mehrmals im Jahr oder dauerhaft Elektrogeräte anbieten und bereitstellen, sind verpflichtet, beim Kauf eines Neugerätes das Altgerät umweltgerecht zurückzunehmen. Ebenso sind diese verpflichtet, Kleingeräte (bis zu 3 pro Kalenderjahr) mit keiner äußeren Abmessung größer als 25cm zurückzunehmen, unabhängig vom Kauf eines Neugerätes.

Alle personenbezogenen Daten vor der Rückgabe bzw. Entsorgung löschen.

In Elektrogeräten enthaltene Batterien und Akkus müssen nach örtlichen Gesetzen oder Anforderungen getrennt von Hausmüll oder Folgeschäden, durch unsachgemäße Handhabung/falscher Verwendung oder durch Mischung der in dieser Bedienungsanleitung enthaltenen Informationen entstehen.

CE Das Produkt entspricht den Anforderungen der EU Richtlinien.

Technische Änderungen vorbehalten. Für Druckfehler übernehmen wir keine Haftung.

SAFETY - EXPLANATION OF NOTES

Please take note of the following symbols and words used in the operating instructions, on the product and on the packaging:

- Information Useful additional information about the product
- Note The note warns you of possible damage of all kinds
- Caution Attention - Hazard can lead to injuries
- Warning Attention - Danger! May result in serious injury or death

PROPER INTENDED USE

The product serves as a mobile light source and is not intended for use in other applications. The product is not suitable for household room lighting and only for use as described in the operating instructions. Use outside that stipulated in the information is improper use and this can result in damage to property or personal injury. We assume no liability for damage caused by incorrect or improper use.

LIITHIUMHALTIGE BATTERIEN UND AKKUS

Kleben Sie bei lithiumhaltigen Batterien und Akkus vor der Entsorgung die Pole ab, um einen äußeren Kurzschluss zu vermeiden. Ein Kurzschluss kann zu einem Brand oder einer Explosion führen.

PRODUKT-BESCHREIBUNG

- Haupt-LED
- Zusatz-LED
- An-/Aus-Taster
- Batteriefach
- Kopfband (universell einstellbar)

temment peuvent présenter une fuite et / ou causer un incendie / une explosion.

Tenir les piles hors de la portée des enfants : risque d'ingestion ou de suffocation.

Ne jamais tenter d'ouvrir, d'écraser, de chauffer ou de mettre en feu une pile / un accu. Ne pas jeter au feu.

Lors de l'insertion des piles, veillez impérativement à la polarité correcte.

Les fuites de piles / les liquides dans les accus peuvent entraîner des brûlures chimiques en cas de contact avec des parties du corps. En cas de contact, rincer immédiatement les emplacements concernés avec de l'eau fraîche et contacter immédiatement un médecin.

Ne pas court-circuiter les broches de raccordement et les piles. Ne pas recharger des piles non rechargeables.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

INBETRIEBNAHME

1x drücken: 25% Modus
2x drücken: 100% Modus
3x drücken: aus

AUTOMATISCHE LEISTUNGSANPASSUNG

Um die Betriebssicherheit und Langlebigkeit des Produktes zu gewährleisten, erfolgt ggf. bei erhöhter Wärmeentwicklung eine automatische Leistungsanpassung. Daher kann es zu Abweichungen der technischen Spezifikationen kommen.

HAFTUNGSAUSSCHLUSSE

Die in dieser Bedienungsanleitung enthaltenen Informationen können ohne Vorankündigung geändert werden. Wir übernehmen keine Haftung für direkte, indirekte, zufällige oder sonstige Schäden oder Folgeschäden, die durch unsachgemäße Handhabung/falscher Verwendung oder durch Mischung der in dieser Bedienungsanleitung enthaltenen Informationen entstehen.

CE Das Produkt entspricht den Anforderungen der EU Richtlinien.

Technische Änderungen vorbehalten. Für Druckfehler übernehmen wir keine Haftung.

SAFETY - EXPLANATION OF NOTES

Please take note of the following symbols and words used in the operating instructions, on the product and on the packaging:

Information Useful additional information about the product

Note The note warns you of possible damage of all kinds

Caution Attention - Hazard can lead to injuries

Warning Attention - Danger! May result in serious injury or death

PROPER INTENDED USE

The product serves as a mobile light source and is not intended for use in other applications. The product is not suitable for household room lighting and only for use as described in the operating instructions. Use outside that stipulated in the information is improper use and this can result in damage to property or personal injury. We assume no liability for damage caused by incorrect or improper use.

LIITHIUMHALTIGE BATTERIEN UND AKKUS

Kleben Sie bei lithiumhaltigen Batterien und Akkus vor der Entsorgung die Pole ab, um einen äußeren Kurzschluss zu vermeiden. Ein Kurzschluss kann zu einem Brand oder einer Explosion führen.

PRODUKT-BESCHREIBUNG

- Haupt-LED
- Zusatz-LED
- An-/Aus-Taster
- Batteriefach
- Kopfband (universell einstellbar)

temment peuvent présenter une fuite et / ou causer un incendie / une explosion.

Tenir les piles hors de la portée des enfants : risque d'ingestion ou de suffocation.

Ne jamais tenter d'ouvrir, d'écraser, de chauffer ou de mettre en feu une pile / un accu. Ne pas jeter au feu.

Lors de l'insertion des piles, veillez impérativement à la polarité correcte.

Les fuites de piles / les liquides dans les accus peuvent entraîner des brûlures chimiques en cas de contact avec des parties du corps. En cas de contact, rincer immédiatement les emplacements concernés avec de l'eau fraîche et contacter immédiatement un médecin.

Ne pas court-circuiter les broches de raccordement et les piles. Ne pas recharger des piles non rechargeables.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

Les batteries rechargeables doivent uniquement être chargées sous la surveillance d'adultes et doivent être retirées de l'appareil avant le processus de chargement.

GENERAL SAFETY INSTRUCTIONS

This product may be used by children from the age of 8 and by persons with reduced physical, sensory or mental abilities or lack of experience and knowledge, if they have been instructed on the safe use of the product and are aware of the hazards. Children are not permitted to play with the product. Children are not permitted to carry out cleaning or care without supervision.

Keep the product and the packaging away from children. This product is not a toy. Children should be supervised in order to ensure that they do not play with the product or packaging.

Avoid eye injuries - Never look directly into the beam of light or shine it into other people's faces. If this occurs for too long, the blue light portion of the beam can cause retinal damage.

Do not expose to potentially explosive environments where there are flammable liquids, dusts or gases.

Never submerge the product in water or other liquids.

All illuminated objects must be at least 5cm away from the lamp. Use the product exclusively with the accessories included with it.

Improperly inserted batteries could leak and/or cause a fire/explosion.

Keep batteries away from children: Risk of choking or suffocation.

Never try to open, crush or heat a standard/rechargeable battery or set it on fire. Do not throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not cover the product - risk of fire.

Throw into a fire.

When inserting batteries, ensure that the batteries are inserted with the correct polarity. Leaking battery fluid can cause irritation if it comes into contact with the skin. Immediately rinse affected areas with fresh water and then seek medical attention.

Do not short-circuit connection terminals or batteries.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

Do not attempt to charge non-rechargeable batteries.

Rechargeable batteries must only be charged under the supervision of an adult and must be removed from the device before being charged.

DANGER OF FIRE AND EXPLOSION

Do not use while still in the packaging.

